

Standard screw holes.  
Do not completely tighten  
screws until AFTER  
adjusting sash height.

Fixing screw.  
Do not install until  
AFTER  
adjusting sash  
height.

1.500 (38.1mm)  
Below lowest  
screw hole

Ø .272 ("1" drill)  
(7.0 mm)  
Hole to seat  
lug in adjuster

Rotate 5mm hex key in either  
direction to raise & lower hinge  
for a total of 3/16" (4.5mm)  
vertical adjustment.

A012 cat12 1211-01 hinge adjuster; date 06/08/12

